



FTC Fact Sheet

This is Cotton Batt Insulation

UltraTouch™ Denim Insulation, Batts, Unfaced

Product	Thickness	Width/Length	Sq. Ft.Bag	Product	Thickness	Width/Length	Sq. Ft.Bag
R-30	8.00"	16.25" x 48"	27.10	R-30	8.00"	15" x 48"	25.00
		24.25" x 48"	40.40			23" x 48"	38.35
R-21	5.50"	16.25" x 94"	53.04	R-21	5.50"	15" x 94"	48.45
		24.25" x 94"	79.15			23" x 94"	74.25
R-19	5.50"	16.25" x 94"	53.04	R-19	5.50"	15" x 94"	48.45
		24.25" x 94"	79.15			23" x 94"	74.25
R-13	3.50"	16.25" x 94"	84.88	R-13	3.50"	15" x 94"	77.52
		24.25" x 94"	126.63			23" x 94"	118.80
R-8	2.00"	16.25" x 94"	129.99	R-8	2.00"	15" x 94"	120.00
		24.25" x 94"	126.34			23" x 94"	122.66

Specialty Products Thickness Width/Length Sq. Ft.Bag

Multipurpose	1.80"	16" x 48"	5.33
Water Heater Jacket	1.80"	48" x 75"	25.0

Read This Before You Buy

What you should know about R-values.

The chart shows the R-value of this insulation. R means resistance to heat flow. The higher the R-value, the greater the insulating power. Compare insulation R-values before you buy. There are other factors to consider. The amount of insulation you need depends mainly on the climate you live in. Also, your fuel savings from insulation will depend upon the climate, the type and size of your house, the amount of insulation already in your house, and your fuel use patterns and family size. If you buy too much insulation, it will cost you more than what you will save on fuel. To get the marked R-value, it is essential that this insulation be installed properly.